250M HDMI EXTENDER WITH TCP/IP

User Manual



1. Product Description The model JC-EX605H includes a transmitter unit (TX) and a receiver unit(RX), working as a pair. It allows for transmission and extension full HD 1080p@60Hz HDMI signal via CAT5e/6 UTP network cable, the transmission distance is up to 250meters; Support point to multi-point over Ethernet switch over IP. At the same time, the signal is stable, and the built-in EDID greatly improves the compatibility of the device. This product is perfect for AV transmission in applications of HD conference system, HD video shooting, HD multimedia education system, HD digital advertising and signage etc.

The device has a long transmission distance, low use cost, convenient installation and good compatibility, and it is a stable and efficient transmission method.

2. Main Features

• Aluminum shell, compact size and Slim design, more beautiful than iron shell, strong anti-interference ; Wall-mounted type is more convenient.

- Distance up to 250m over UTP CAT6 cable.
- Video resolution max up to 1920*1080@60Hz.
- Support 1 to many receivers transmit (253pcs RX over Ethernet switch) .
- Support IR(38khz) signal pass back control.
- HDMI 1.3 and HDCP 1.2 standard.
- High compatibility, can auto-match source and display device.
- Built-in automatic adjustment system, make the image smooth, clear and stable.
- Built-in ESD protection system; Simple to install, plug and play.
- TCP/IP Ethernet communication.
- Pure Ethernet , Simple Cabling .
- Application Fields: 1: N Solution (Shop, classrooms, Monitor, Digital Camera, TCP/IP Network).
- Ordinary 100M or 1000M Ethernet switch.

3. Advantage

	d output	HDMI output HDMI input
	work interface	V/RST STA PWR DG 5V Power input PWR: Power light
	recet you long proce avec	PVR: POWPr UPDT
System	reset key,Long press exect	STA: System indicator lamp
System	Impedance	
System		STA: System indicator lamp
	Impedance	STA: System indicator lamp
Jystem	Impedance Interface	STA: System indicator lamp 100Ω 3.5mm earphone seat
	Impedance Interface Signal direction	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional
IR	Impedance Interface Signal direction Signal type	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital
	Impedance Interface Signal direction Signal type IR frequency	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz
IR	Impedance Interface Signal direction Signal type IR frequency Interface	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz RJ45 (568B)
IR	Impedance Interface Signal direction Signal type IR frequency Interface Transmission distance	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz RJ45 (568B) UTP CAT6 -250m ; CAT5E-200m
IR Ethernet	ImpedanceInterfaceSignal directionSignal typeIR frequencyInterfaceTransmission distancePower supply	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz RJ45 (568B) UTP CAT6 -250m ; CAT5E-200m The power adapter: DC 5V
IR	ImpedanceInterfaceSignal directionSignal typeIR frequencyInterfaceTransmission distancePower supplyPower dissipation	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz RJ45 (568B) UTP CAT6 -250m ; CAT5E-200m The power adapter: DC 5V MAX 4W
IR Ethernet	ImpedanceInterfaceSignal directionSignal typeIR frequencyInterfaceTransmission distancePower supplyPower dissipationTemperature	STA: System indicator lamp 100Ω 3.5mm earphone seat Unidirectional Digital 38kHz RJ45 (568B) UTP CAT6 -250m ; CAT5E-200m The power adapter: DC 5V MAX 4W Operating: -5°C ~ +70°C

5. Panel

<u>Sender:</u>



Receiver :



6. Installation Steps

- 1. Connect the provided DC/5V power supplies to the power socket of the transmitter and the receiver,
- 2. Connect an HDMI cable between the HDMI input port of transmitter and the HDMI output port of the video source,
- 3. Connect the HDMI output port of receiver to the display device with HDMI cable,
- 4. Connect the transmitter RJ45 port to the receiver RJ45 port using a single CAT6 cable.
- 5. IR function---connect the IR TX (the bigger) cable to the HDMI receiver, connect IR RX cable to the HDMI transmitter and the IR TX must face to the controlled device.

7. Packing List

- HDMI extender transmitter x 1
- HDMI extender receiver x 1
- IR sender and receiver cable x 1
- Power adapter x 2
- Instruction manual x 1

8. Using Diagram & Application

One to one



One to many

